

KLIME-EZEE MOBILE STEPS USER INSTRUCTIONS

We take pride in over 25 years of experience in the manufacturing industry. All of our products are crafted to the highest engineering standards, using premium quality components and finished to exceptional standards.

For optimal use, it is essential that all personnel are fit, healthy, fully aware of, and appropriately trained in accordance with 'Working at Height Regulations.'

We recommend that the designated safety officer conducts assessments, provides training, and ensures proper maintenance of the products to safeguard operators and extend the longevity of the safety equipment.

Follow ALL guidelines	Read operating instructions	Carry out regular maintenance	Call us for more information
------------------------------	------------------------------------	--------------------------------------	-------------------------------------

At all times, users should adhere to the following guidelines

- Always inspect the product for damage prior to each use and never use a mobile step or equipment that shows signs of damage.
- Use the product only on firm, level ground.
- Avoid over-reaching, as this can cause the unit to tip.
- Face the ladder when ascending, except when using our Truck-Dock Range, which features a 45-degree angle of ascent designed to allow safe forward descent.
- Only one person should be on the mobile step at a time.
- Carry only minimal tools or items while using the mobile step, and take their weight into consideration when calculating the maximum Safe Working Load (SWL).
- Never exceed the maximum SWL, which is clearly marked on the product.
- Ensure that the user is adequately trained in the safe use of the equipment.
- Do not use the mobile step in wet or windy conditions; all environmental factors must be considered to avoid accidents.
- Perform a comprehensive inspection at least once every six months.

Operating instructions : spring loaded models

- Ensure the unit is clear of any objects and free from grease or damage.
- Check that there are no overhead obstructions or restrictions in the area where you plan to move the unit.
- Verify that the spring-loaded castors are in the mobile position (this means the legs are lifted off the floor).
- Stand at the front of the unit, at the base of the treads, and move the unit into the desired position by gripping both handrails.
- Once the unit is positioned, you are ready to use it.
- To activate the plunger castors, hold both handrails and begin walking up the steps, keeping your body weight central - do not pull yourself onto the unit.
- Ascend the treads slowly, ensuring your body weight is centered on each tread. Stand evenly on the working platform area. The castors will retract, and the legs will make contact with the floor.

- When on the working platform, always stand centrally and adhere to any safety information labels located on the unit.
- When descending, face the working platform and walk slowly down, one step at a time. As you descend, the feet will lift off the floor, and the unit will become mobile again.

Note: The plunger castors are weight-sensitive; leaning out of the unit will cause the legs to lift. Always remain centered when using this equipment.

Braking System Instructions: Other Models

- Ensure the unit is clear of any objects and free from grease or damage.
- Check that there are no overhead obstructions or restrictions in the area where you plan to move the unit.
- To make the step mobile, stand in front of the unit and pull the central or side braking lever towards you, securing it into the loading lug. This will engage the front swivel castors onto the floor, allowing you to move the steps into position.
- Stand at the front of the unit, at the base of the treads, and maneuver the unit into the desired position by gripping both handrails (where applicable).
- Once the mobile step is positioned, disengage the central or side braking lever to safely ascend the step. Move the lever handle out of the loading lug, ensuring the front feet are flat on the floor after doing so.
- Ascend the unit by holding both handrails (where applicable) and walk up the treads slowly, keeping your body weight centered on each tread. Stand evenly on the working platform.
- Always stand centrally on the working platform and follow any safety information labels located on the unit.
- When descending, face the working platform and walk slowly down, one step at a time. Unless using our KTD Range, which has a 45-degree angle of ascent designed to allow the user to safely descend forward.

When using a mobile step with gated exits and accessories

- Ensure they are securely fastened and do not obstruct movement.
- Ensure they are free from rust and that all locks & latches are in working order.
- When using the unit ensure that any exits are fully closed and locked behind you.

After care

Always store the product in a clean, dry area with minimal traffic to prevent damage from equipment such as fork trucks.

If any substance is spilled on the unit, clean it immediately to ensure no residue remains.

Ensure that any bottom exits are closed to prevent unauthorised personnel from accessing the unit.

Maintenance instructions

For additional maintenance advice and to access our inspection checklist, please visit our website at www.klime-ezee.com.

We are committed to ensuring that all of our products are safe and easy to use. We recommend consulting with your Health & Safety representative prior to use to conduct a risk assessment and provide training tailored to your specific requirements for the product's use.